

OPTI-TRANS JET LITE









PRINT YOUR IMAGE:

1. Mirror image your artwork before printing design on the heat transfer paper. Single-sheet feeding is recommended.





PREPARE SHEETS:

- 1. Print your image on the white imaging side of the sheet (vs. side with a pattern).
- 2. Check your printer settings; single-sheet feeding is recommended.
- 3. Trim your printed image. As with any transfer, it is recommended to trim the design before transferring. For best results, (optional), use an image with rounded edges to avoid corner liftoff after washing.





HEAT PRESS MACHINE: (skip to 3b if using a hand iron)

1. Preheat press to 345-355f degrees.

TIP. If fabric is wrinkly, press fabric first to ensure flatness, then let cool.

- 2. Place transfer paper with design facing down, (white side down), in desired position on fabric.
- 3. Using above recommended temperature, apply firm pressure for 20 seconds.
- TIP. Heat presses vary. Test to see which temp works best with your machine.
 - 4. After pressing, hot peel transfer immediately from garment. Caution, transfer will be hot.



TRANSFERRING IMAGE TO SUBSTRATE WITH A HEAT PRESS:

PREHEAT	TEMPERATURE	PRESSURE	TIME	TYPE OF PEEL
✓	345 °- 355 °f	Firm/Heavy	205	нот!



HAND IRON:

- 1. Preheat iron to hottest "Cotton" setting. NO steam.
- 2. Prepare a hard surface, NOT an ironing board.
- 3. Place a telfon sheet, pillowcase or t-shirt between your hard surface and your garment to allow the heat to penetrate the transfer. With firm pressure, press and move slowly across garment, holding each press for 45 seconds, ensure all edges and corners are firmly pressed and overlapped. Continue and press over the entire image again holding for 45 seconds until entire image has been pressed. Total ironing time should be 5 to 6 minutes if using a 8.5" x 11" size transfer image.
- 4. After pressing, hot peel transfer immediately from garment. Caution, transfer will be hot.

TIPS:

- Do not use a laser printer
- Use in well-ventilated area.
- For best results, store unused paper in a cool, dry area for 12-24 hours before using and do not remove from carton until you are ready to use. After opening the package, store paper in the poly bag. This will help improve the quality of your printed image and reduce copier jamming as well.

WASHING INSTRUCTIONS:





- Leave finished item for at least 24 hours before washing.
- Fabrics may then be machine washed separately (inside out), DO NOT USE BLEACH or bleach additive detergent) in cold water.
- Do NOT use fabric softener. Dry at normal setting; do not dry clean



Important Note: Heat presses vary in accuracy. Conduct your own test to determine the best time and temperature to use with your equipment.